

## COORDINATION PARAMETERS AT GÖTEBORG LANDVETTER AIRPORT

Season:	Summer 2018 (S18)
IATA level of coordination:	Level 3
Opening hours:	H24
Coordinator:	Airport Coordination Sweden (ACS)
Maximum number of movements yearly:	80 000*

\*Propeller aircrafts below MTOW 10 000 kg excluded.

### Runway Capacity

#### Total movements during 1 rolling hour:

Time	Movements
06.05 – 22.55 local time	36
23.00 – 06.00 local time	10

#### Total number of passenger departures:

Region	20 rolling minutes	1 rolling hour
Non Schengen	6	-
Schengen/Domestic	17	-
<b>Total (all regions)</b>	<b>21</b>	<b>36</b>

### Stand Capacity

#### Passenger flights:

Region	Number of stands	Comment
Non Schengen	2	Non Schengen only
Non Schengen/Schengen/Domestic	4	Flexible gates
Schengen/Domestic	13	Schengen/Domestic only

#### Flights simultaneous:

Flight Type	Number of stands	Comment
Passenger	19	
Cargo/Mail	8	
Other (Non Passenger flights)	5	Remote stand (towing only)

**Business and General Aviation simultaneous (EFS, EMS, Jivair and SAA excluded):**

Aircraft Type	Number of stands	Comment
FA7X and larger	2	
GLF4 and smaller	6	
Light aircrafts (MTOW less than 2 000 kg)	1	
<b>Maximum aircrafts in total</b>	<b>6</b>	<b>Number of GA flights in total</b>

*Note:*

- Maximum of 6 aircrafts in total/1 aircraft types FA7X and larger with Code F traffic on stand 43.
- Pushback is normal procedure for aircrafts Code B and larger. Contact handling agent before arrival if pushback is not possible.

**Total of capacity for Code E and F aircrafts:**

Aircraft Category	Number of stands
Code F	1
Code E	5
<b>Code E and F simultaneous</b>	<b>4 Code E and 1 Code F</b>

*Note:*

- B763 Winglets will be allocated to Code E stands.

**The following time frames below apply for nose docking:**

Seats	Turnaround	Arrival	Departure
Up to 189 seats	60 minutes	50 minutes	50 minutes
190 – 250 seats	90 minutes	60 minutes	60 minutes
More than 250 seats	120 minutes	90 minutes	90 minutes