

COORDINATION PARAMETERS AT GÖTEBORG LANDVETTER AIRPORT

Season:	Winter 2017 (W17)
IATA level of coordination:	Level 3
Opening hours:	H24
Coordinator:	Airport Coordination Sweden (ACS)

Runway Capacity

Total movements during 1 rolling hour:

Time	Movements
06.05 – 22.55 local time	36
23.00 – 06.00 local time	10

Total number of passenger departures:

Region	20 rolling minutes	1 rolling hour
Non Schengen	6	-
Non Schengen/Schengen/Domestic	17	-
Total (all regions)	21	36

Stand Capacity

Passenger flights:

Region	Number of stands	Comment
Non Schengen	2	Non Schengen only
Non Schengen/Schengen/Domestic	4	Flexible gates
Schengen/Domestic	13	Schengen/Domestic only

Non Passenger flights and Cargo/Mail flights:

Flight Type	Number of stands	Comment
Cargo/Mail	8	
Other (Non Passenger flights)	5	Remote stand (towing only)

Business and General Aviation simultaneous (EFS, EMS, Jivair and SAA excluded):

Aircraft Type	Number of stands	Comment
FA7X and larger	2	
GLF4 and smaller	7	
Maximum aircrafts in total	7	Number of GA flights in total

Note:

- Maximum of 6 aircrafts in total/1 aircraft types FA7X and larger with Code F traffic on stand 43.
- Pushback is normal procedure for aircrafts Code B and larger. Contact handling agent before arrival if pushback is not possible.

Total of capacity for Code E and F aircrafts:

Aircraft Category	Number of stands
Code F	1
Code E	5
Code E and F simultaneous	4 Code E and 1 Code F

Note:

- B763 Winglets will be allocated to Code E stands.

The following time frames below apply for nose docking:

Seats	Turnaround	Arrival	Departure
Up to 189 seats	60 minutes	50 minutes	50 minutes
190 – 250 seats	90 minutes	60 minutes	60 minutes
More than 250 seats	120 minutes	90 minutes	90 minutes